



# RENOGRUNT 410

Cement, thin-layer self-leveling grout 2-20mm

**Areas of application:** Grout intended for manual or mechanic execution of leveling-finishing layers on indoor flooring bases.  
It can be used for leveling surfaces of new and modernized floors and other elements (eg stairs of internal stairs) in housing and general, especially in public facilities such as: hospitals, health centers, kindergartens, nurseries, etc. Suitable for laying on rigid and load-bearing anhydrite, cement and concrete foundations, etc. Used as a leveling layer for ceramic tiles, synthetic floor coverings, panels, parquet floors, etc.  
It is perfect for levelling cement beds of heated floors.

- Properties:**
- self-leveling
  - Indoor use
  - Manual and machine application
  - The possibility of treading after 5h.
  - Easy to use
  - High mechanic durability
  - Under parquet, panels, carpet flooring, tiles

**Application procedure:**

Technical data	
Item no.	14268
Packaging type	
Quantity per unit	25 kg
Unit per pallet	48 Pcs/pallet
Consumption	1.5 kg/m <sup>2</sup> /mm
Application time	30 min
Pressure resistance (28 d)	≥ 7 MPa
Compressive strength (28 d)	≥ 30 MPa
Layer thickness	2 - 20 mm
Soluble chromium VI content	≤ 0.0002 %
Amount of water required	approx. 6 l/bag
Reaction to fire	A1 <sub>f</sub>
Possibilities to enter	approx. 5 hours
Suitable for floor cover	approx. 7 days
Mortar class	CT-C30-F7

**The product conforms to:** • EN 13813

- Material base:**
- Portland cement
  - Calcium aluminate cement
  - Mineral fillers
  - Modifying additives

**Surface:** Repair slits and larger cracks of a bed e.g. using 428 levelling mortar. Concrete beds must be at least 6 months old, and cement screeds - at least 4 weeks old and moisture cannot be higher than 2%.

**Types of substrate:**  
**Concrete, reinforced concrete:** Prime with CONTACT GRUNT 307  
**Cement screed:** Prime with GRUNTOLIT-W 301 or EXPERT 6  
**Terrazzo:** Degrease, clean, and execute a contact layer made of elastic tile adhesive or prime CONTACT GRUNT 307.



## RENOGRUNT 410

Cement, thin-layer self-leveling grout 2-20mm

<b>Preparation:</b>	<p>Pour the dry mix gradually to a container with a sufficient amount of clean, cool water, mixing manually or using a low-speed mixer to produce homogenous, lump-free mass. Leave to mature for 5 minutes, and then mix again.</p> <p>If there is a need to use a part of the packaging, the entire dry compound must be carefully stirred because during transport components could be separated.</p> <p>Do not mix the hardened grouting mixture again.</p>
<b>Application procedure:</b>	<p>Pour out to the desired level, dear with a spiked roller.</p> <p>Before starting work, determine the level to which the screed will be poured. The level of the screed can be determined by using special benchmarks or benchmarks made by themselves from the wire or by using embedded dowels with screws in the ground, the heads of which determine the level of the layer being made. In existing expansion joints, expansion joints should be made in the poured leveling and smoothing layer. It is recommended to start work at the wall furthest from the entrance to the room and lead with 40 cm wide strips. In the case of rooms with a large width, it is recommended to separate smaller working fields (with a width of 3-6 m, depending on the speed of pouring the mass). After pouring, the mass should be spread with a steel trowel and bled with a spiked roller. The work should be carried out without interruption until the entire floor area in the room is covered.</p>
<b>Application conditions:</b>	<p>Apply in temperatures from +5 °C do +25 °C. These temperatures apply to air, groundwork and product temperature. All groundworks should be load-bearing, tight, stable, cleared and, if necessary, primed with EXPERT 6 or GRUNTOLIT-W 301. Prime poor-quality groundworks with EXPERT 5 - deep-penetration primer. Smooth substrates that require increased adhesion are recommended to be primed with GRUNT CONTACT 307.</p> <p>Before pouring out the grout, expansion joints in the groundwork must be properly secured as to ensure they are not filled with grout. Insulation expansion joints must be executed as to separate the grout from the wals and other elements, applying dedicated expansion tape, or Styrofoam panels preferably 10mm thick.</p>
<b>Instructions:</b>	<p>Freshly laid mass must be protected against premature drying by reducing heating, protected against direct sunshine, draughts, too low moisture of air etc. Such conditions must be maintained also during performance of the works. (Unstable surface layers must be removed. Repair slits and larger cracks of bed.) Familiarize with the product data sheet before use.</p> <p>Avoid contact with skin and protect eyes. Detailed guidelines are included in the material safety data sheet.</p>
<b>Storage:</b>	<p>Up to 6 months from the date of manufacture, in dry areas and in non-damaged factory packaging.</p>
<b>General information:</b>	<p>This product data sheet replaces all its previous versions. The information, included in this technical card, represents our current knowledge and practical experience. This is general information only which shall not obligate the manufacturer to take any responsibility either for workmanship or for the manner of use. For there may be differences and specific execution conditions. The product shall be applied in accordance with required technical knowledge and OHS rules. Avoid contact with skin and protect eyes. In case of contact with eyes, rinse them up with a large quantity of clean water and consult a doctor. It shall be recommended to use gloves, safety goggles and protective clothing.</p> <p>All technical data is given for the temperature of 20 degrees Celsius. These temperatures apply to air, bed and embedded material.</p>